



# INSTALLATION MANUAL

---








**MA01 square 115**

# INSTALL TOOL



A1  X1	A2  X1	A3  X2	A4  X1	A5  ST4X25 X8	A6  X1
A7  X1	A8  X2	A9  ST4X12 X2	A10  X1	A11  X2	A12  X2
A13  X1	A14  X4	A15  ST4X12 X28	A16  X1	A17  ST4X10 X4	A18  X1
A19  X1	A20  X1	A21  X1	A22  X1	A23  X1	A24  ST4X25 X6
A25  X1	A26  X1	A27  X1	A28  X1	A29  X1	A32  X1

# WaterArrangementMap



Note:  
After the bottom basin is leveled up and down The track follows the bottom basin and the top cover, There is deformation in radian size, corresponding to Bend the lower rail to the top cover Consistent with the bottom basin radian

